



PREPARING YOUR KIT FOR PCB ASSEMBLY

For consignment service, simply mail us your printed circuit boards and components and Advanced Assembly will machine-assemble the order.

KIT LABELS

Advanced Assembly offers a one-of-a-kind service for all consignment orders: custom kit labels. Kit labels improve accuracy and increase the fluidity of overall production, saving you time and money. Parts arriving without proper documentation may experience a delay in processing.



Kit labels are created directly from your BOM & include:

- 1** Build Number
- 3** Quantity
- 5** Reference Designators
- 2** Manufacturer Part #
- 4** Description Value Pkg
- 6** Bar Code for Receiving

PACKAGING & SHIPPING

- Ship all parts in anti-static carriers or moisture sensitive packaging.
- Place kit labels on the outside of parts packaging
- Include your Advanced Assembly assigned BUILD# with every shipment
- Refer to your Order Confirmation for shipping address

Send files online at www.aapcb.com, via email to sales@aapcb.com or to your account executive.

Advanced Assembly is the original and industry-defining quick-turn PCB Assembly service. With our extensive expertise, experience, and operational capacity, we can guarantee the best and fastest assembly in the industry. You give us your design, we make it exactly when you need it, and it works, every time.

20100 E. 32nd Pkwy. #225 | Aurora, CO 80011 | www.aapcb.com | (800) 838-5650